

# Flashing Firmware

ASI controllers ship with a bootloader that allows new firmware provided by ASI to be installed in the field. Firmware will be provided by ASI as needed. The bootloader itself should not be changed.

Updating update on the the MS2000 or RM2000 controller is done with the ASI Console application. Instructions can be found at

<https://www.asiimaging.com/support/downloads/asi-console#updatingfirmware>

Instruction on how to program the TG1000 “Tiger” controller is done with the Tiger Console application. Instructions can be found at

<https://www.asiimaging.com/support/downloads/tiger-controller-console>

[tech note](#), [ms2000](#), [tg1000](#)

From:

<http://www.asiimaging.com/docs/> - **Applied Scientific Instrumentation**

Permanent link:

[http://www.asiimaging.com/docs/flashing\\_ms2000\\_controller](http://www.asiimaging.com/docs/flashing_ms2000_controller)

Last update: **2024/04/16 18:47**

