

Command:RELOCK (RL)

Shortcut	RL
Format	RL
Firmware Module Required	CRISP or AF-DUAL

Turns on the CRISP laser and initiates a LOCK state using previously saved reference values. Same as LOCK for AF-DUAL systems.

Reply

:A is returned upon receipt of the command.

[commands](#), [ms2000](#), [afdual](#)

From:

<https://www.asiimaging.com/docs/> - **Applied Scientific Instrumentation**

Permanent link:

<https://www.asiimaging.com/docs/commands/relock>

Last update: **2023/03/31 04:04**

