

# Nikon TE2000 Left-Hand Z-Axis Drive Installation Procedure

The procedure below outlines the steps necessary to install the ASI Microscope Focus Controller Drive onto the Nikon Eclipse TE2000 microscope.

To perform the following steps you will need the following tools:

Small cross blade screw driver 3mm, 5/64 and 7/64 inch hex wrenches The hex wrenches are provided by ASI.

The procedure has four parts:

1. Removing the left fine focus knob
2. Installing the baseplate
3. Installing and aligning the motor drive assembly
4. Installing the motor drive cover plate & fine focus knob

## Part 1 - Removing the Left Fine Focus Knob & Brass Adapter plate

Remove the left fine focus knob from the microscope as follows:




Figure 1



Figure 2

Use screwdriver to remove two screws. Pull knob straight off to expose brass adapter plate, and use Allen wrench to loosen two set screws and remove brass adapter plate.

- Use screwdriver to remove two screws. Remove the fine focus knob by grasping it firmly and pulling it straight off.
- Use Allen wrench to loosen two set screws and remove brass adapter plate.

## Part 2 - Installing the Baseplate



Figure 3 Installed baseplate





Figure 4 Baseplate clearance holes



Figure 5: Baseplate clamp

Locate the baseplate. If the motor drive is attached to the base plate use the 3mm Allen wrench to remove the horizontal adjustment screw to remove the drive from the base plate. Position the base plate so that the large baseplate is on the left side of the microscope. Lift the front of the microscope up and slide the baseplate under the microscope so that the horizontal adjustment bar is centered under the left focus knob as shown in figure # 3. There are two clearance holes, as shown in figure # 4, for two screws on the bottom of the microscope. When the baseplate is “about” in the correct position you will feel the screw drop into the holes. Leave the clamp shown in figure # 5 loose at this time.

## Part-3 Installing & Aligning the Motor Drive




Figure 6 Loosen Vertical adjustment screws




Figure 7 Install Z-drive over fine focus shaft




Figure 8 Tighten the clamp on the fine focus shaft

- Loosen the two Vertical screws that secure the drive to the adjustment bar as shown in figure 6. Use the 7/64"hex wrench. Loosen the screws just enough so that the drive can slide easily in the groove in the adjustment bar.
- Locate the ASI fine focus motor drive and vertical adjustment screw (M4 x 12 hex head screw removed when the base plate was installed). Align the drive shaft on the ASI drive with the microscope fine focus shaft and slide the motor drive over the fine focus shaft as shown in figure 7.
- Rotate the drive so that the tab on the bottom of the adjustment bar fits into the groove on the baseplate. Install, but do not completely tighten the vertical adjustment screw ( figure # 9 ) to hold thedrive in place. Please Note the baseplate may need to be moved to properly align the adjustment bar. When the drive is properly aligned use the 7/64" Allen wrench to securely tighten the drive shaft clamp as shown in figure 8.



Figure 9 Horizontal Adjustment screw

- Slide the motor drive up and down, forward and backward slightly while turning the right fine focus knob until it is in the position where minimum drag is felt on the right focus knob. Secure the motor drive into position by tightening the horizontal and vertical adjustment screws.
- Use the 5/64" Allen wrench to tighten the base plate clamp set screw shown in figure # 10 to secure the base plate to the microscope



- Recheck the alignment by noting the drag on the right fine focus knob. No noticeable drag should be felt at any point with in the full 360 degrees of rotation. If any noticeable drag is felt loosen the Vertical & Horizontal adjustment screw and repeat the step d above if necessary.

## Part 4-Installing the motor drive cover plate & fine focus knob




Figure 11 Installing cover



Figure 12 Installing brass knob adapter

Locate the motor drive cover. Remove the 4/40 button head screws from the base plate with the 1/16 " Allen wrench. Position the motor drive cover over the motor drive assembly and secure in place using the 4/40 button head screws as shown in figure # 11.

Slide the microscope brass knob adapter over the shaft extension and press it on all the way. Secure it in place by tightening the two set screws. Install the knob onto the brass adapter plate.

This completes the procedure for installing the ASI motor drive on to the Nikon Eclipse Microscope.

[zdrive, nikon, te2000](#)

From:

<https://asiimaging.com/docs/> - Applied Scientific Instrumentation



Permanent link:

[https://asiimaging.com/docs/nikon\\_te2000\\_left\\_z\\_install](https://asiimaging.com/docs/nikon_te2000_left_z_install)

Last update: **2021/09/23 17:15**